



Vendor Item # H50152BA  
Target DPCI #: 084 09 3001  
Description: Stone Pagoda

Questions, Problems, Missing Parts? Before returning to your retailer,  
**PLEASE CALL CUSTOMER SERVICE at (866) 728-6187**  
9am – 5pm EST, Mon – Fri or e-mail [customerservice@srg-usa.com](mailto:customerservice@srg-usa.com).

**PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.**

Unpack all parts from Styrofoam and bubble wrap inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product. Please contact customer service for replacement.

**CARTON CONTENTS:**





| Part# | Description  | Quantity |
|-------|--------------|----------|
| 01.   | Light lid    | 1        |
| 02.   | Light socket | 1        |
| 03.   | Pedestal     | 1        |
| 04.   | Transformer  | 1        |

**TOOLS REQUIRED FOR ASSEMBLY:**

- No tools required

**ASSEMBLY INSTRUCTIONS:**

1. Unpack the contents of the box and check to make sure that all items are accounted for and in good condition.
2. Select a flat, level surface for the assembly and final location of your fountain.
3. Place the pedestal on a horizontal flat surface. (Fig 1)
4. Align the light socket with the pedestal by wedge plate (note to run the light cord out through the middle hole of pedestal and draw it out from the cord slot at the bottom of the pedestal. (Fig 2)
5. Align the wedge on the light lid with the notch of the light socket. Then cover the light lid and rotate it clockwise to lock into place. (Fig 2)
6. Connect the light cord and transformer power and connect the transformer to a GFCI outlet. The product will begin to function as intended. (Fig 3)



NOTE: The diagrams shown are for illustrative purposes only and are not to scale.

**MAINTENANCE OF YOUR FOUNTAIN:**

1. When the product is not in used for an extended period of time, disconnect the power.
2. If the light is burning out, please change it with the same model.

**LIGHT INSTRUCTIONS:**


**LIGHT BULB REPLACEMENT INSTRUCTIONS:**

1. If the light bulb is burned out, turn off the transformer power. Wait a moment until the light is fully cooled.
2. Grasp firmly and revolve to pull out the glass tube.
3. Remove the burned out bulb from the light socket and Insert a new replacement bulb (NOT INCLUDED) into the light socket. And please revolve the glass tube into the light socket.

## **IMPORTANT SAFETY INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS**

### **WARNING** - Lighted lamp is HOT!

- Lamp gets HOT quickly! Do not touch the lens, cover or enclosure.
- Unplug and allow the lamp to cool before handling the lamp.
- Keep lamp away from materials that may burn.
- Do not touch the bulb at any time. Use a soft cloth. Oil from skin may damage lamp.
- Do not operate the lamp with a missing or damaged lamp covers.



### **CAUTIONS:**

1. Please make sure the plug surface dry before connecting the power to avoid damaging the appliance.
2. Please make sure you are using the proper power source as indicated.
3. Keep the power cord away from source of heat and fire.
4. The fountain is not a toy! Always it away from children and pets.

### **TRANSFORMER INSTRUCTIONS:**

#### **IMPORTANT SAFETY INSTRUCTIONS**

When using electrical product, basic precautions should always be practiced including the following:

1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
2. Read and follow all instructions that are on the product or provided with the product.
3. For a cord-connected or direct plug-in power unit, do not use an extension cord.
4. Reference the National Electrical Code, ANSI/NFPA 70, specifically for the installation of wiring and clearances from power and lighting conductors.
5. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.
6. For a cord-connected or direct plug-in power unit, do not install or use within 10 feet of a pool.
7. For a cord-connected or direct plug-in unit, do not use in bathroom.
8. For cord-connected power unit, user should pay attention to below statement:



### **WARNINGS:**

1. Risk of Electric Shock. When used outdoors, install only to a covered Class A GFCI protected receptacle that is weatherproof with the power unit connected to the receptacle. If one is not provided, contact a qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover.
2. Risk of Fire. Installation involves special wiring methods to run wiring through a building structure. Consult a qualified electrician
3. Mount the unit at a height greater than 1 foot from the ground surface.
4. Do not use with receptacles that are weatherproof only when the receptacle is covered (attachment plug cap not inserted and receptacle cover closed).

**SAVE THESE INSTRUCTIONS** - This manual contains important safety and operating instructions for power units.

***Light is replaceable with model 12v 10w halogen light***

### **SAVE THESE INSTRUCTIONS!**

Each Peaktop product may have variations in texture, finish and appearance from one unit to the next. This enhances the beauty of the product and makes your Peaktop product uniquely individual. Some products and finishes are intentionally weathered or worn in appearance for aesthetic design.

**Ref. # DE99166**

**Printed in China**