



Item # 188545

Waterfall Kit (Model # WFK)

Questions, Problems, Missing Parts?

Before returning to your retailer, call our customer service department at
1- (866) -728-6187, 9 a.m. – 5 p.m. EST (Monday-Saturday) or email at us customerservice@srq-usa.com
Please have your model number available

Parts List

Part #	Description	Quantity
1	Waterfall	1 pc
2	Plastic Tube – ½ in. ID	10ft
3	Pump – MD170	1 pc

No Tools Required for Assembly

Warnings

- ⚠ To reduce the risk of electrical shock, connect only to a properly grounded, grounding type receptacle (GFCI).
- Do not exceed the voltage shown on the pump.
- Always disconnect pump from the power source before beginning any maintenance or work on the pump.
- Inspect cord for damage before installation and/or maintenance. Replace the entire pump assembly if damage is found.
- Do not remove the grounding pin from the power cord plug.

Cautions

- Use a proper power source as indicated on the pump label.
- Keep the cord away from high temperatures or other heat sources.
- Avoid using the pump when water temperatures fall below 41° F.
- Do not pump heated liquids.
- Do not let the pump run dry. Pump must be completely submerged for proper operation and cooling.
- Operate in freshwater only. Avoid heavily chlorinated water & water with high PH levels.
- Do not lift the pump by its power cord.

Assembly Instructions

- Remove the parts from the package. Untie pump's power cord.
- Place the waterfall on a level surface at the edge of your pond.
- Connect the plastic tube from the adapter on the bottom of the waterfall to the pump. Push the connector firmly into the pump outlet.
- Place the pump in the desired location in the pond, ensuring that it is completely submerged in the water. Raise the pump off the pond floor to ensure that it is above any dirt that will collect, as this will adversely affect pump performance.
- Connect the power cord to the power source.

Care and Maintenance

- Keep water clean. Using distilled water will reduce mineral deposits and improve water clarity.
- Clean the product periodically to prevent mineral deposits and contamination.
- Disconnect the power and empty the waterfall if it will not be used for an extended time.
- Do not operate waterfall in temperatures below 41°F (5°C). If waterfall is kept outdoors in freezing temperatures, make sure all water is removed and the unit is completely dry or freeze damage may occur.

Troubleshooting

If the pump fails to operate;

- Check to make sure the power cord is plugged in and the pump is getting power.
- Check the pump outlet and any tubing, fountains, spitters etc. for kinks or obstructions.
- Remove the inlet screen and/or pump cover, and impeller housing to expose the impeller. Turn the impeller to ensure that it is not broken or jammed.

If the performance of the pump is not satisfactory or the pump does not flow evenly.

- Check to make sure the pump is completely submerged in water.
- Check to make sure the impeller and the housing are clean.
- Adjust flow control.

