

## INSTRUCTIONS

Item Description: Savannah Fountain

Vendor Item#: F40421AA

Questions, Problems, Missing Parts? Before returning to your retailer, CALL OUR CUSTOMER SERVICE DEPARTMENT at Tel 1 (866) 728-6187 9 a.m.– 5 p.m. EST, Monday-Friday or e-mail customerservice@srg-usa.com

### PARTS LIST:

Part#	Description	Quantity
1.	Fountain Bonsai	1
2.	Pump	1
3.	Basin	1
4.	Pedestal	1

**\*NO TOOLS REQUIRED FOR ASSEMBLY**

### ASSEMBLY INSTRUCTIONS:

- Place the product on a flat horizontal surface.
- Run the pump cable down through the hole of pedestal and out through the notch at the bottom, and then wedge the basin to the pedestal levelly and securely.
- Insert the connector of PVC at the bottom of fountain bonsai to the outlet of pump. Wedge the fountain bonsai to the basin levelly and securely.
- Add clean water into the basin, the water level should be approx.20mm below the edge of the basin.
- Connect the pump to a proper power source; the product will start to function as intended.

### MAINTENANCE:

- Keep water clean – using distilled water will reduce mineral deposits and improve water clarity.
- Clean the product periodically to prevent mineral deposits and contamination.
- Disconnect the power and empty the basin if fountain will not be used for an extended time.
- If installed outdoors and in a freeze-area of the country, ensure all water is removed and the unit is completely dry. **Product is NOT To be Operated Below 41°F(5°C) Freeze Damage May Occur.**



### SPECIAL WARNINGS & CAUTIONS:

#### WARNINGS:

- To reduce the risk of electric shock, use only on portable self-contained fountains no larger than 5 feet in any dimension.
- To reduce risk of electric shock, connect only to a properly grounded outlet.
- Inspect cord for damage before installation and/or maintenance. Replace entire pump/cord assembly if damage is found.
- Do not remove the grounding pin from the cord.
- Do not exceed voltage shown on pump.

#### CAUTIONS:


- Use proper power source as indicated on the water pump label. Keep the cord away from high temperature or heat source.
- Keep fountain out of reach of children.
- If in a freeze-area, remove water from fountain and pump. It is also recommended to remove and store the fountain and pump indoors during freezing conditions.
- Always disconnect from electrical outlet before handling the pump.
- Do not let pump run dry.
- Do not pump heated liquids.
- Operate in freshwater only.
- Pump must be completely submerged for proper operation and cooling.
- To avoid any injury, HANDLE WITH CARE when carrying and assembling the products.

#### HINTS & TROUBLESHOOTING:

- Ensure the pump's flow control switch is set to Maximum (+) before operating. Once flow is established, the pump's flow can be adjusted downward to a desired level, if maximum is too high.
- If the pump operates, but there is no flow, check to ensure the pump is fully submerged.
- If the pump operates, but there is no flow, check the supply tubing for kinks and correct.
- If the pump operates, but there is no flow, and if the pump is submerged and there are no kinks in the supply tubing, lift the pump from the water. Remove supply tubing at pump outlet and clean tubing inside and out if necessary. Reset pump in water (outlet side up) and once water begins to flow, reattach supply tubing.
- Place some plants (not included) around the base to enhance aesthetics.

Each Peaktop product may have variations in texture, finish and appearance from one unit to the next. This enhances the beauty of the product and makes your Peaktop uniquely individual. Some products and finishes are intentionally weathered or worn in appearance for aesthetic design.

***Pump is replaceable with Peaktop model #HI-350pump.***



NOTE: The diagrams shown are for illustrative purposes only.

Ref.:#:  
**PRINTED IN CHINA**